

Call Progress Decoder Field Installation Instructions for TeleRadio

The CP-1 decoder is easily field installed in a TeleRadio. Unplug the TeleRadio power before starting. Simply remove the top from the TeleRadio enclosure and locate the three sets of gold plated pins near the back of the TeleRadio labelled CP-1 Connectors. The CP-1 board has mating connectors that allow it to drop directly onto the TeleRadio pins. Once connected, the CP-1 is operational. Adjustment is usually not required, but is covered in the CP-1's operating instructions, if needed.

